
## Heyboer Transformer Measurements



These dimensions are for layout purposes, please wait for the actual components before drilling your chassis!

	HTS-5199 Power Transformer	HTS-5200 Output Transformer
A	4 7/16	3 <sup>5</sup> / <sub>16</sub>
В	3 <del>1</del> 8	3 1 8
С	3 <sup>13</sup> / <sub>16</sub>	3 <sup>13</sup> / <sub>16</sub>
D	4	$2\frac{13}{16}$
E	$3\frac{1}{4}$	2 <del>1</del> /8
F	$2\frac{1}{2}$	$2\frac{1}{2}$
G	2 <sup>3</sup> / <sub>8</sub>	1 <sup>5</sup> / <sub>16</sub>
Н	17/8	17/8

All measurements are in inches.

Any questions or comments are welcome. M. Taylor, wrecked2k4@yahoo.com